

BRACKET ASSEMBLY



1. Prepare a *triangular bracket*, two *screws* and a *central holding bracket*.
2. Make sure the *central holding bracket* is positioned as per picture 1 and place the *triangular bracket* on top.
3. Screw both *screws*, in *pre-drilled holes*, connecting the *brackets* together.
4. Repeat for the other side to complete the *bracket*.



5. Completed assembly of the 2 *triangular* with the *central holding bracket* — view from the *inner side*.
6. Completed assembly of the 2 *triangular* with the *central holding bracket* — view from the *rear*.
7. Middle *bracket* is shipped ready for fitting on the watering lines.
8. Assembled *brackets*.

